



# ChiplessSolutions

## Chipless Firmware Manual for Epson SC-P600, P607, P608, PX5V2

**Step 1.** Connect printer to PC by proper USB cable.

**Step 2.** Put printer in **Firmware Update Mode**.  
(Ink cartridges and printer drivers are not required).

Power OFF the printer and not more then in 1 minute **press and hold** buttons:

**BACK + HOME + POWER** – wait 3-5 sec and release **BACK** button, release other buttons when printer go in the firmware update mode - You'll see **WHITE** text - Firmware Update Mode . If text is in **red** color - that is wrong mode. Try once more time.



**Step 3.** Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.



When firmware update is completed - confirm that new firmware version is displayed on the LCD.

Press **POWER** – printer will turn **OFF**.


Name ^	Date modified	Type	Size
Resources	3/29/2018 6:08 PM	File folder	
_ReadMe.doc	3/22/2018 4:50 PM	Microsoft Word document	137 KB
e_dge321.dll	2/7/2017 3:08 PM	Application extension	16 KB
ENBoost.dll	6/23/2017 6:33 PM	Application extension	156 KB
<b>EPFWUPD.exe</b>	6/23/2017 6:36 PM	Application	3,633 KB
FWE857TL.efu	2/6/2018 4:57 PM	EFU File	6,692 KB
Unzip32.dll	2/7/2017 3:08 PM	Application extension	100 KB

**Step 4.** Switch ON the printer.

**Step 5.** Run **License.exe** file, Select Language. Select printer model.

Name ^	Date modified	Type	Size
 _ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
 License.exe	3/29/2018 3:04 PM	Application	4,018 KB

**Step 6.** Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).



Chipless Solutions - www.ChiplessSolutions.com

English Russian

USB001:(SC-P600 Series) Refresh

Printer's ID

Input your activation code

GFM8G-JG69D-CMD2C-KC7TP-B8HKY

OK Cancel

Copy

Activate online


Recovery code

Paste

Recover

**WARNING: Copy and Save Recovery Code** from the Recovery Code window. It will be required if printer will update firmware from Epson server and You wish to restore Chipless Firmware in Your printer.

To restore chipless firmware – paste saved Code to Recovery Code window and Click **Recover button**.



We recommend You to disable automatic firmware update in printer settings!

**ChiplessSolutions.com**