



ChiplessSolutions

Chipless Firmware Manual for

Epson WF-4720, WF-4730, WF-4734



Step 1. Connect printer to PC by proper USB cable.

Step 2. Put printer in **Firmware Update Mode**.
(Ink cartridges and printer drivers are not required).

Power OFF the printer and not more than in 1 minute **press and hold**:

POWER BUTTON and **RIGHT UPPER DISPLAY CORNER** – wait 3 sec until Blue Power Led turn ON and release all buttons. On printer monitor you will see **WHITE text - Firmware Update Mode**.

If text is in **red color** - that is wrong mode. It means You hold too long time. Try once more time.




Step 3. Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.

When Firmware Update is complete confirm that **new Firmware Version is displayed** on the LCD.

Press on the **CENTER of TOUCH SCREEN** – printer will turn **OFF**.

Name ^	Date modified
Resources	3/29/2018 6:08 PM
_ReadMe.doc	3/22/2018 4:50 PM
e_dge321.dll	2/7/2017 3:08 PM
ENBoost.dll	6/23/2017 6:33 PM
EPFWUPD.exe	6/23/2017 6:36 PM
FWE857TL.efu	2/6/2018 4:57 PM
Unzip32.dll	2/7/2017 3:08 PM




Step 4. Switch ON the printer.

Step 5. Run **License.exe** file, Select Language. Select printer model.


Name ^	Date modified	Type	Size
_ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
License.exe	3/29/2018 3:04 PM	Application	4,018 KB

Step 6. Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).



WARNING: Copy and Save Recovery Code from the Recovery Code window. It will be required if printer will update firmware from Epson server and You wish to restore Chipless Firmware in Your printer.

To restore chipless firmware – paste saved Code to Recovery Code window and Click **Recover button**.



We recommend You to disable automatic firmware update in printer settings!

ChiplessSolutions.com