



# ChiplessSolutions

## Chipless Firmware Manual for Epson SC-P400, P407, P408, PX7V2

**Step 1.** Connect printer to PC by proper USB cable.

**Step 2.** Put printer in **Firmware Update Mode**.  
(Ink cartridges and printer drivers are not required).

Power OFF the printer and not more then in 1 minute **press and hold** buttons:

**ROLL + INK + CANCEL + POWER** – wait 3-5 sec - hold this buttons until **Ink, Paper and Power LEDs are ON** - then release all buttons - printer is in the firmware update mode now.



**Step 3.** Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.



When Firmware Update is complete confirm that **new Firmware Version is displayed** on the LCD.

Press **OK** button – printer will turn **OFF**.


Name ^	Date modified	Type	Size
Resources	3/29/2018 6:08 PM	File folder	
_ReadMe.doc	3/22/2018 4:50 PM	Microsoft Word Document	137 KB
e_dge321.dll	2/7/2017 3:08 PM	Application extension	16 KB
ENBoost.dll	6/23/2017 6:33 PM	Application extension	156 KB
<b>EPFWUPD.exe</b>	6/23/2017 6:36 PM	Application	3,633 KB
FWE857TL.efu	2/6/2018 4:57 PM	EFU File	6,692 KB
Unzip32.dll	2/7/2017 3:08 PM	Application extension	100 KB

**Step 4.** Switch ON the printer.

**Step 5.** Run **License.exe** file, Select Language. Select printer model.

Name ^	Date modified	Type	Size
 _ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
 License.exe	3/29/2018 3:04 PM	Application	4,018 KB

**Step 6.** Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).



The screenshot shows the 'Chipless Solutions' application window. At the top, there are language buttons for 'English' and 'Russian'. Below them is a dropdown menu showing 'USB001:(SC-P400 Series)' and a 'Refresh' button. A section labeled 'Printer's ID' contains a text box with the activation key 'GFM8G-JG69D-CMD2C-KC7TP-B8HKY', which is highlighted with a green box and labeled with a green arrow and the number '2'. To the right of this text box are 'Copy', 'OK', and 'Cancel' buttons. The 'OK' button is highlighted with a green box and labeled with a green arrow and the number '3'. Below the activation key section is a 'Recovery code' section with a large empty text box and 'Paste' and 'Recover' buttons. On the right side of the window, there is an 'Activate online' button, which is highlighted with a green box and labeled with a green arrow and the number '1'.

To restore chipless firmware – paste saved Code to Recovery Code window and Click **Recover button**.



**ChiplessSolutions.com**