



ChiplessSolutions

Chipless Firmware Manual for Epson SC-P800

Step 1. Connect printer to PC by proper USB cable.

Step 2. Put printer in **Firmware Update Mode**.
(Ink cartridges and printer drivers are not required).

Power OFF the printer and not more then in 1 minute **press and hold** buttons:

BACK + HOME + POWER – wait 3-5 sec and release **BACK** button, release other buttons when printer go in the firmware update mode - You'll see **WHITE** text - Firmware Update Mode . If text is in **red** color - that is wrong mode. Try once more time.



Step 3. Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.



When firmware update is completed - confirm that new firmware version is displayed on the LCD.

Press **POWER** – printer will turn **OFF**.


Name ^	Date modified	Type	Size
Resources	3/29/2018 6:08 PM	File folder	
_ReadMe.doc	3/22/2018 4:50 PM	Microsoft Word Document	137 KB
e_dge321.dll	2/7/2017 3:08 PM	Application extension	16 KB
ENBoost.dll	6/23/2017 6:33 PM	Application extension	156 KB
EPFWUPD.exe	6/23/2017 6:36 PM	Application	3,633 KB
FWE857TL.efu	2/6/2018 4:57 PM	EFU File	6,692 KB
Unzip32.dll	2/7/2017 3:08 PM	Application extension	100 KB

Step 4. Switch ON the printer.

Step 5. Run **License.exe** file, Select Language. Select printer model.

Name ^	Date modified	Type	Size
 _ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
 License.exe	3/29/2018 3:04 PM	Application	4,018 KB

Step 6. Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).



The screenshot shows the 'Chipless Solutions' application window. At the top, there are language buttons for 'English' and 'Russian'. Below them is a dropdown menu showing 'USB001:(SC-P800)' and a 'Refresh' button. A section titled 'Printer's ID' contains a text box with the activation code 'GFM8G-JG69D-CMD2C-KC7TP-B8HKY', which is highlighted with a green box and labeled with a green arrow '2'. To the right of this text box are 'Copy' and 'Activate online' buttons. The 'Activate online' button is highlighted with a green box and labeled with a green arrow '1'. Below the text box are 'OK' and 'Cancel' buttons. The 'OK' button is highlighted with a green box and labeled with a green arrow '3'. At the bottom, there is a 'Recovery code' section with a large empty text box and 'Paste' and 'Recover' buttons.

To restore chipless firmware – paste saved Code to Recovery Code window and Click **Recover button**.



ChiplessSolutions.com