



ChiplessSolutions

Chipless Firmware Manual for Epson WF7710, WF-7711, WF-7715, WF7720, WF-7721, PX-M5080F, PX-M5081F


Step 1. Connect printer to PC by proper USB cable.

Step 2. Put printer in **Firmware Update Mode**.
(Ink cartridges and printer drivers are not required).

Power OFF the printer and not more then in 1 minute **press and hold** buttons:

STATUS + 4 + 7 + POWER – wait until on printer monitor you will see **WHITE text - Firmware Update Mode** – then **Release all buttons**.

If text is in **red color** - that is wrong mode. Try once more time.



Step 3. Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.

When Firmware Update is complete confirm that **new Firmware Version is displayed** on the LCD.

Press **0 (zero) button** – printer will turn **OFF**.

Name ^	Date modified	Type	Size
Resources	3/29/2018 6:08 PM	File folder	
_ReadMe.doc	3/22/2018 4:50 PM	Microsoft Word Document	137 KB
e_dge321.dll	2/7/2017 3:08 PM	Application extension	16 KB
ENBoost.dll	6/23/2017 6:33 PM	Application extension	156 KB
EPFWUPD.exe	6/23/2017 6:36 PM	Application	3,633 KB
FWE857TL.efu	2/6/2018 4:57 PM	EFU File	6,692 KB
Unzip32.dll	2/7/2017 3:08 PM	Application extension	100 KB

Step 4. Switch ON the printer.

Step 5. Run **License.exe** file, Select Language. Select printer model.

Name ^	Date modified	Type	Size
_ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
License.exe	3/29/2018 3:04 PM	Application	4,018 KB

Step 6. Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).

The screenshot shows the 'Chipless Solutions' software window. At the top, there are language buttons for 'English' and 'Russian'. Below them is a dropdown menu showing 'USB001: (WF-7710 Series)' and a 'Refresh' button. A section labeled 'Printer`s ID' contains a modal dialog titled 'Input your activation code'. This dialog has a text field with the activation key 'GFM8G-JG69D-CMD2C-KC7TP-B8HKY', an 'OK' button, and a 'Cancel' button. To the right of the dialog are 'Copy' and 'Activate online' buttons. Below the dialog is a 'Recovery code' section with a large empty text area, a 'Paste' button, and a 'Recover' button. Three red arrows indicate the sequence: arrow 1 points to the 'Activate online' button, arrow 2 points to the activation key text field, and arrow 3 points to the 'OK' button.

Chipless Solutions - www.ChiplessSolutions.com

English Russian

USB001: (WF-7710 Series) Refresh

Printer`s ID

Input your activation code

GFM8G-JG69D-CMD2C-KC7TP-B8HKY

OK Cancel

Copy

Activate online

Recovery code

Paste

Recover

To restore chipless firmware – paste saved Code to Recovery Code window and Click **Recover button**.



ChiplessSolutions.com