



ChiplessSolutions

Chipless Firmware Manual for Epson XP243, XP-244, XP-247

Step 1. Connect printer to PC by proper USB cable.

Step 2. Put printer in **Firmware Update Mode**.
(Ink cartridges and printer drivers are not required).

Power **OFF** the printer and not more than in 1 minute **press and hold** buttons:

COPY + COLOR COPY + NETWORK + POWER – wait until **ALL LEDs except Power LED are ON** – then **Release all buttons**. Printer is in Firmware Update mode.
If indication differs - that means it is wrong mode. Try once more time.



Step 4. Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.

After Firmware Update is finished - all LEDs will blink simultaneously.
Press **STOP** button – **printer will turn OFF**.

Name ^	Date modified	Type	Size
Resources	3/29/2018 6:08 PM	File folder	
_ReadMe.doc	3/22/2018 4:50 PM	Microsoft Word Document	137 KB
e_dge321.dll	2/7/2017 3:08 PM	Application extension	16 KB
ENBoost.dll	6/23/2017 6:33 PM	Application extension	156 KB
EPFWUPD.exe	6/23/2017 6:36 PM	Application	3,633 KB
FWE857TL.efu	2/6/2018 4:57 PM	EFU File	6,692 KB
Unzip32.dll	2/7/2017 3:08 PM	Application extension	100 KB

Step 5. Switch ON the printer.

Step 6. Run **License.exe** file, Select Language. Select printer model.

Name ^	Date modified	Type	Size
_ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
License.exe	3/29/2018 3:04 PM	Application	4,018 KB

Step 7. Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).

The screenshot shows the 'Chipless Solutions' application window. At the top, there are language buttons for 'English' and 'Russian'. Below them is a dropdown menu showing 'USB001:(XP-240 Series)' and a 'Refresh' button. A section labeled 'Printer's ID' contains a blue header 'Input your activation code' and a text box with the key 'GFM8G-JG69D-CMD2C-KC7TP-B8HKY'. To the right of this text box are 'Copy' and 'Activate online' buttons. Below the text box are 'OK' and 'Cancel' buttons. At the bottom, there is a 'Recovery code' section with a large empty text box and 'Paste' and 'Recover' buttons. Teal arrows and numbers indicate the steps: arrow 1 points to the 'Activate online' button, arrow 2 points to the activation key text box, and arrow 3 points to the 'OK' button.

Language	Printer's ID	Activation Key	Buttons
English / Russian	USB001:(XP-240 Series)	GFM8G-JG69D-CMD2C-KC7TP-B8HKY	Copy, Activate online, OK, Cancel
Recovery code			Paste, Recover

