



ChiplessSolutions

Chipless Firmware Manual for Epson XP340

Step 1. Connect printer to PC by proper USB cable.


Step 2. Put printer in **Firmware Update Mode**.
(Ink cartridges and printer drivers are not required).

Power **OFF** the printer and not more than in 1 minute **press and hold** buttons:

STOP + LEFT ARROW + DOWN ARROW + POWER – wait until printers LCD will display “Program Update Mode” in **WHITE** color– then **Release all buttons**.

Printer is in Firmware Update mode.

If text is in red color - that means it is wrong mode. Try once more time.



Step 4. Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.

When firmware upload is completed confirm that new version is displayed on LCD.
Press **OK** button – **printer will turn OFF**.

Name ^	Date modified	Type	Size
Resources	3/29/2018 6:08 PM	File folder	
_ReadMe.doc	3/22/2018 4:50 PM	Microsoft Word Document	137 KB
e_dge321.dll	2/7/2017 3:08 PM	Application extension	16 KB
ENBoost.dll	6/23/2017 6:33 PM	Application extension	156 KB
EPFWUPD.exe	6/23/2017 6:36 PM	Application	3,633 KB
FWE857TL.efu	2/6/2018 4:57 PM	EFU File	6,692 KB
Unzip32.dll	2/7/2017 3:08 PM	Application extension	100 KB

Step 5. Switch **ON** the printer.

Step 6. Run **License.exe** file, Select Language. Select printer model.

Name ^	Date modified	Type	Size
_ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
License.exe	3/29/2018 3:04 PM	Application	4,018 KB

Step 7. Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).

The screenshot shows the 'Chipless Solutions' software window. At the top, there are language buttons for 'English' and 'Russian'. Below them is a dropdown menu showing 'USB001:{XP-340 Series}' and a 'Refresh' button. A section labeled 'Printer's ID' contains a text box with the activation code 'GFM8G-JG69D-CMD2C-KC7TP-B8HKY'. To the right of this text box are 'Copy', 'OK', and 'Cancel' buttons. Below the text box is a large empty text area for a 'Recovery code', with 'Paste' and 'Recover' buttons to its right. The 'Activate online' button is located to the right of the activation code text box. Numbered arrows indicate the steps: (1) points to the 'Activate online' button, (2) points to the activation code text box, and (3) points to the 'OK' button.

To restore chipless firmware – paste saved Code to Recovery Code window and Click **Recover button**.



ChiplessSolutions.com