



ChiplessSolutions

Chipless Firmware Manual for Epson X6000


Step 1. Connect printer to PC by proper USB cable.

Step 2. Put printer in **Firmware Update Mode**.
(Ink cartridges and printer drivers are NOT required).

Power OFF the printer, then press and hold such buttons:

STOP + LEFT + DOWN then POWER – wait 3 seconds until on printer monitor you will see **WHITE text** - Program **Update Mode** – then **Release ALL buttons**.

If text is in **red color** - that is wrong mode. Try once more time.




Step 3. Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.

When Firmware Update is complete confirm that **new Firmware Version is displayed** on the LCD.

Press **POWER** button – printer will turn **OFF**.

Name ^	Date modified	Type	Size
Resources	3/29/2018 6:08 PM	File folder	
_ReadMe.doc	3/22/2018 4:50 PM	Microsoft Word Document	137 KB
e_dge321.dll	2/7/2017 3:08 PM	Application extension	16 KB
ENBoost.dll	6/23/2017 6:33 PM	Application extension	156 KB
EPFWUPD.exe	6/23/2017 6:36 PM	Application	3,633 KB
FWE857TL.efu	2/6/2018 4:57 PM	EFU File	6,692 KB
Unzip32.dll	2/7/2017 3:08 PM	Application extension	100 KB



Step 4. Switch ON the printer.

Step 5. Run **License.exe** file, Select Language. Select printer model.

Name ^	Date modified	Type	Size
_ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
License.exe	3/29/2018 3:04 PM	Application	4,018 KB

Step 7. Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).

