



ChiplessSolutions

Step by Step Manual for making chipless printers:

Epson WF-C5710, WF-C5790

Step 1. Connect printer to PC by proper USB cable.

Step 2. Put printer in **Firmware Update Mode**:
(Ink cartridges and printer drivers are not required).

Power OFF the printer and not more then in 1 minute **press and hold** buttons:

4 + 7 + JOB/STATUS + POWER – wait 3 sec until on printer monitor You will see **Firmware Update Mode** in WHITE color - then release all buttons - printer is in the Firmware Update Mode now. If text is in Red color – that is **wrong** mode. Try once more time until you get text in white color.



Step 3. Upload Firmware to printer.

Run **EPFWUPD.EXE** file and follow all steps until Firmware will upload in printer.

When Firmware Update is complete confirm that **new Firmware Version is displayed** on the LCD.

Press on the **CENTER of TOUCH SCREEN** – printer will **turn OFF**.


Name ^	Date modified	Type	Size
Resources	3/29/2018 6:08 PM	File folder	
_ReadMe.doc	3/22/2018 4:50 PM	Microsoft Word Document	137 KB
e_dge321.dll	2/7/2017 3:08 PM	Application extension	16 KB
ENBoost.dll	6/23/2017 6:33 PM	Application extension	156 KB
EPFWUPD.exe	6/23/2017 6:36 PM	Application	3,633 KB
FWE857TL.efu	2/6/2018 4:57 PM	EFU File	6,692 KB
Unzip32.dll	2/7/2017 3:08 PM	Application extension	100 KB

Step 4. Switch ON the printer.

Step 5. Run **License.exe** file, Select Language. Select printer model.


Name ^	Date modified	Type	Size
_ReadMe.pdf	3/29/2018 5:50 PM	Adobe Acrobat Document	571 KB
License.exe	3/29/2018 3:04 PM	Application	4,018 KB

Step 6. Click **Activate Online** button (1), Enter **Activation Key** (2) and click **OK** (3).



WARNING: Copy and Save Recovery Code from the Recovery Code window. It will be required if printer will update firmware from Epson server and You wish to restore Chipless Firmware in Your printer.

To restore chipless firmware – paste saved Code to Recovery Code window and Click **Recover** button.



Serial
ID Co
KA77
+H54!
Qzww
+7Ulr
HnMF

- Recovery code

2YDeWkEKHhQAWe9Dnr08hZEt20cAAAAASgAAAGL0H5
v6APhtq78krqMNTaOG55bXAwAAAGwA
AADnAAAAAnAAAAACC6GBAAACNEIWEkADAAMiABFTgE/
//////////zMzMzMzMzMzMzMzMzM
zMzMzMzMzMzMzMzMzMzMzMzMzMzMw=

Paste

Recover

Save this Recovery Code in proper place.
It will be required if You want to recover
chipless firmware after new Epson update

ChiplessSolutions.com